



Promax Floating Out-take Installation Instructions

The tank will need to be empty to install this fitting.

You cannot use the existing tank outlet to connect the Floating Out-take.

The kit includes the new Tank Fitting to be installed into the base of tank side-wall.

1. Select the best position for the Floating Out-take
2. Carefully drill a hole through the tank wall just big enough to allow the shank of the Tank Outlet Fitting to slide through.
3. Remove the nut from the Tank Outlet Fitting
4. Slide the shank of the fitting through the hole from the inside of the tank
5. Wind the nut onto the shank and tighten to seal

Tips:

1. To help get the tank outlet into position from the manhole use a wooden pole or wire to lever into position.
2. To help seal the fitting to the tank wall use a smear of silicone.

The floating out-take lies suspended within the tank to allow the best water to be drawn off just below the surface

